



## PLASTERBOARD ANGLES

### FIXING INSTRUCTIONS

All angles and surfaces must be free from dust and contaminants

#### PLASTERBOARD ANGLE FIXING

PTT Plasterboard angles fixed to plasterboard and fibre cement sheeting should be fixed in accordance with the plasterboard and fibre cement manufacturer's recommendations usually using a spray adhesive such as PTT Corner Bead Spray Adhesive (52-PCBSA) or equivalent or plaster based cement or rust proof fasteners.

#### STORING OF TRIMS

Plaster Trims should be stored flat and below 25°C and free from dust and contamination.