



## RENDER TRIMS - FIXING INSTRUCTIONS

### RENDER EXTERNAL TRIM FIXING

Render Trims should be fixed in accordance with the system or render manufacturer's directions which is usually adhering the trims with the applicable render compound or cement based construction adhesive (Patch Render) making sure the cement based adhesive fully covers the substrate & the trim to obtain complete adhesion between the two surfaces.

### REVEAL & SILL TRIM FIXING

Fix in accordance to the system or compound manufacturer's recommendations making sure the cement based adhesive (Patch Render) fully covers the substrate & the trim to obtain complete adhesion between the two surfaces.

### SEALING BETWEEN TRIMS & WINDOWS / SGD

Render Reveal & Sill Trims should be wiped clean using a dry clean cloth and flashed with an acetone cleaner (e.g Bostik 5077 or Sika-Cleaner 205) and sealed between the trim and the framing with Bostik Seal & Flex, Sikaflex-521 UV or Fixseal MSP15 (Metholated Spirits can be used as a cleaner for Fixseal MSP15 only).

### STORING OF TRIMS

All trims and surfaces must be free from dust and contaminants.

All Trims should be stored flat and below 25°C and free from dust and contamination.

**Note:** Some Non render based adhesives may contain Zylene solvents, which can soften PVC if applied unevenly.